



How to Plug In the Nextplay NP109CR

If the device is not powering on, this guide will show you how to plug it in.

Written By: Rosana Cheruvelil



Step 1 — How to Plug In the Nextplay NP109CR



- Find the power cord.

⚠ Make sure that it is unplugged from the outlet. This is to make sure that no power is flowing through and you are not injured.

Step 2



- Check to make sure that the power cord is connected to the device. If it is not connect the smaller end to the back of the device.

Step 3



- Check to make sure that the power cord is connected to an outlet. If not, take the two-pronged end and plug it in to an outlet. The device is now correctly plugged in.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-05 08:04:08 AM.